


HOW TO MEASURE FOR WINDOW BLINDS

OUTSIDE FIX / FACE FIX



Measure Width

1. Measure the horizontal width of the area you wish to cover in 3 places (top, middle & bottom)
2. Add 100mm onto each side for overlap.

Measure Length / Drop

3. Measure the vertical height of the area you wish to cover in 3 places (left, centre & right)
4. Add at least 100-250mm above the window frame so it does not block the view when kept pulled up or stacked (stack heights differ per product)

INSIDE MOUNT / TOP FIX

Length – Left

Length – Middle

Length – Right

Measure Width

1. Measure the horizontal width of the inside of the window frame (for inside mount) in 3 places (top, middle & bottom). This is the width of the blind.

Measure Length / Drop

2. Measure the vertical height of the inside of the window frame (for inside mount) in 3 places (left, middle & right). This is the length / height of the blind.

